





### Applied Nanotechnology for Human Space Exploration

Leonard L. Yowell

NASA Johnson Space Center

February 20th, 2007


E-Mail: leonard.yowell-1@nasa.gov

Phone: 281-483-2811




# NASA's Strategic Vision







# **Exploration Architecture**



Planetary Operations (Human/Robotic)

ISS Operations



## Cannot Be Met with Conventional Materials **Future Exploration Mission Requirements**

## Vehicles and Habitats



- Reduced mass and volume
- High strength
- Thermal and radiation protection
- Self-healing, self-diagnostic
  - Multi-functionality
- Improved durability
- Environmental resistance (dust, atmosphere, radiation)




- Reduced mass
- Increased functionality and mobility
  - Thermal and radiation protection
- Environmental resistance



- Reduced mass and volume
- Reduced power requirements
- Increased capability, multifunctionality








# Nanomaterials: Single Wall Carbon Nanotubes

### **Unique Properties**


- Exceptional strength
- Interesting electrical properties (metallic, semi-conducting, semi-metal)
- High thermal conductivity
- Large aspect ratios
- Large surface areas



Single Wall Carbon Nanotube

C<sub>60</sub>, Nanotubes, and Atoms

Size Comparison -



### Possible Applications

- High-strength, light-weight fibers and composites
- Nano-electronics, sensors, and field emission displays
- Radiation shielding and monitoring
- Fuel cells, energy storage, capacitors
- Biotechnology
- Advanced life support materials
- Electromagnetic shielding and electrostatic discharge materials
  - Multifunctional materials
- Thermal management materials


### **Current Limitations**

- High cost for bulk production
- Inability to produce high quality, pure, type specific SWCNTs
- Variations in material from batch to batch Growth mechanisms not thoroughly
- Characterization tools, techniques and protocols not well developed

understood




### Applied Nanotechnology at JSC: **Fundamentals to Applications**



APPLICATIONS	PARTNERS	1	7	3	4	s.
Supercapacitors	EP, GRC, Industry	X	×	×	×	
ESD / EMI Shielding	EV, OA, Rice, UTPA, UTD, Industry	×	×	×		
Regenerable CO <sub>2</sub> Removal	EC, ARC, Rice, UTA Industry	×	×			
Proton Exchange Membrane – PEM - Fuel Cells	EP, GRC, Industry	X	X			
Water Disinfection & Recovery	EC, Industry	X	X			
Active / Passive Thermal Management Materials for Space	EC, Rice, Industry	X	X			
Multifunctional Materials: Thermal Radiation & Impact Protection (TRIPS)	ES3, ARC, Rice, Industry	×	×	1		
Nanotube-Based Structural Materials & Advanced Repair	EC, MA, ES3, Rice	×	X			
Radiation Dosimeter	NX, Rice, PV, Ames	×				



# **Technology Readiness Levels (TRL)**



Actual system "flight proven" through successful mission operations

Actual system completed and "flight qualified" through test and demonstration (Ground or Flight)

System prototype demonstration in a space environment

System/subsystem model or prototype demonstration in a relevant environment (Ground or Space

Component and/or breadboard validation in relevant environment Component and/or breadboard validation in laboratory environment

Analytical and experimental critical function and/or characteristic proof-of-concept

Technology concept and/or application formulated

Basic principles observed and reported




# Growth, Modeling, Diagnostics and Production

Objective: Ensure a reliable source of single wall carbon nanotubes with tailored properties (length, diameter, purity, chirality)

### **Laser Ablation**

Graphite Co, Ni Catalysts Fullerenes + SWCNT + impurities

- Batch process
- ~1g/day
- Large diameters (~1.4nm)





Modeling, Diagnostics, and Parametric Studies

Nanotechnologies,

Small diameters (0.9nm)

Continuous process


Carbon

CO2 + SWCNT + impurities

Fe, Ni Catalysts 900-1200C 10-40 atm

00+00

High Pressure CO (HiPco)










# Growth, Modeling, Diagnostics and Production

**April 2004** anotechnology anoscience Journal of




A Special Issue on

Single-Walled Carbon Nanotubes **Growth Mechanisms** 

Carl D. Scott and Sivaram Arepalli








# Characterization: Purity, Dispersion & Consistency





Arepalli, et al., Carbon, 2004

### **Processing**





\* Dispersion

\* Purification

\* Functionalization

\* Surface Area \* Alignment









# Nanoelectronics: Enabling Technologies

### Nano-Fabrication



(10,10) Armchair
Tube

Nano-Characterization



Type-Specific
Nanotube
Synthesis







# Applications for Human Space Exploration

### Multi-functional /

### Structural Materials

- Primary structure (airframe)
- Inflatables

### Power / Energy Storage Materials

- Proton Exchange Membrane (PEM) Fuel Cells
- Supercapacitors / batteries

The Market

### Electromagnetic / Radiation Shielding and Monitoring

- ESD/EMI coatings
- Radiation monitoring

## Advanced Life Support

- Regenerable CO<sub>2</sub> Removal
- Water recovery

## Thermal Protection and Management

- Ablators and ceramic nanofibers
- TPS repair materials
- Passive / active thermal management (spacesuit fabric, avionics)

## Nano-Biotechnology

- Health monitoring (assays)
- Countermeasures




## **Exploration Life Support**

### CHALLENGE:

Supply the daily needs of humans for long duration missions

- Air Revitalization
- Food Management
- Solid Waste Management
- Thermal Control
- Water Reclamation



Human consumable and throughput values in kg/crewmember/day Klaus et al, 2005





### Atmosphere Revitalization System **Exploration Life Support:**

#### MISSION:

- Vehicle cabin atmospheric pressure & quality
- Atmospheric gas storage, supply and distribution
- Carbon dioxide partial pressure control
  - Trace contaminant & particulate control
- Resource recovery, storage and distribution
- Lower spacecraft complexity = Lower risk

Lower risk = Greater safety



	2006	2008	2006 2008 2010 2012 2014 2016 2018 2020	2012	2014	2016	2018	2020
Crew Exploration Vehicle	PC	PDRA						
Lunar Sortie			PD	PDR	Hum	Human Landing	a Bu	
Lunar Outpost						PDR		
Systems Analysis	Sis							
Engineering Subsystem & Subsy						<		
Simes i librato				1		1		
Air Revitalization Systems	Ope Ad Parti	n Loop Ivanced culate	Open Loop Regenerative Advanced Adsorbants Particulate Management	0)	Pre Closed	Pressure Systems Closed Loop Regenerative	stems	ve



# Advanced Life Support: Regenerable CO<sub>2</sub> Removal

### **CHALLENGE:**

- Long duration space flight requires a regenerable system for air revitalization
- NASA need: lower mass, higher performance, reduced volume



Current RCRS materials:

Zeolites and aminecoated polymer beads.

To be replaced by



Single Wall Carbon Nanotube (SWCNT) Structure

### SOLUTION:

- Carbon Nanotubes: superior surface area & thermal conductivity
- Functionalized with CO<sub>2</sub> scrubbing chemistry less volatile
- Suitable for both EVA and vehicle applications
- Applicability to smokestack applications on Earth


### COLLABORATION:

- Rice University: Nanotube functionalization
- Primary amine chemistry
- Requirements for space systems

NASA Ames:

JSC (EC):

- Nanomaterials for trace contaminant control system & CO<sub>2</sub> Sensors
- Energy industry participation interest



Micro-scale testing with thermo-gravimetric analysis











# Exploration Life Support: Regenerable CO<sub>2</sub> Removal


### NanoMaterial Solution:

- Use SWCNT functionalized with CO<sub>2</sub>/H<sub>2</sub>O scavenging amines
- Amines require lower energy for regeneration than present molecular sieve
- Higher surface area reduces system size/ weight



## Nanotube functionalization chemistry (Chattopadhyay et al, 2005)








# **Exploration Life Support: Water Recovery**

- Transport and storage of wastewater from human interfaces
- Primary processing: organic and nitrogenous contaminant reduction
- Secondary processing: inorganic contaminant reduction
- Brine dewatering: water removal from highly concentrated brine
- Post-processing and disinfection: polishing to meet potability standards
- Storage and transport of potable water prior to consumption





# Advanced Life Support: Water Disinfection / Recovery

### CHALLENGE:


- NASA requires renewable chemical-free systems to purify water in space
- Current solution: lodine toxic to astronauts and non-regenerable

### SOLUTION:

- C<sub>60</sub> /fullerene enhances disinfection property of UV light
- Singlet oxygen production enhances the rate at which bacteria are killed
- Chemical-free system for closed loop water purification
- Commercial Potential Portable water disinfection devices


### **COLLABORATION:**

- NASA JSC Advanced Life Support (EC)
- Rice University: C<sub>60</sub> deposition



UV light energizes fullerenes. Upon relaxation, photons are emitted and the excited fullerenes interact with oxygen molecules in water to produce singlet oxygen.

Singlet oxygen kills bacteria.



Water purifier U



**UV Light source** 



# Power & Energy: Supercapacitors

Power-Energy Tradeoff

Fuel Cell

104

### **CHALLENGE:**

- NASA requires reliable, robust power sources suitable for both EVA and vehicle applications
  - NASA requires increased power & energy densities, increased cycle life, reduced mass

Supercapacitor

Battery

Specific Energy (Wh/kg)

104

103

10

Specific Power (W/kg) 102

Charger

#### SOLUTION:

- Carbon nanotube surface area and nanoporosity superior to current materials for electrolyte ion support
- Carbon nanotube electrolyte supports: enhanced electrical and thermal conductivity
- Potential for enhanced performance and longer cycle life

### **COLLABORATION:**


Separator materials NASA Glenn:

Requirements •JSC (EP):

Functionalized nanomaterials •Georgia Tech:

Improved fabrication & ReyTech Corp.:

packaging





Supercapacitor test cell

/ Institute

Georgia Tech



## Power & Energy: Fuel Cells

### **CHALLENGE:**

- sources suitable for both EVA and vehicle NASA requires reliable, robust power applications
- **ං**ර cycle life, power increased increased NASA requires energy densities, reduced mass

Electrode

(GDL) Layer

#### Membrane NafionTM Prototype Membrane Electrode Assembly Gas Diffusion Carbon Fiber Nanotube

Nanotube Electrode Carbon Fiber

(GDL)

#### **SOLUTION:**

- Novel carbon nanotube high surface area, high thermal & high gas diffusivity catalyst support
- Reduced activation polarization increased reliability
- Higher power density from more efficient utilization of platinum catalysts


### **COLLABORATION:**

NASA Glenn:

• JSC (EP):

High temperature membranes Testing, requirements





**PEM Fuel Cell Schematic** 

(Dept. of Energy)



## NanoMaterials for EMI Shielding

### **CHALLENGE:**

susceptibility characteristics of electronic, electrical and electromechanical equipment and subsystems Control of electromagnetic emission and for space exploration

### SOLUTION:

- Single-wall carbon nanotubes (SWCNT) offer low material density and high electrical conductivity
  - Can be integrated into polymer matrices as well as applied onto surfaces as thin transparent coatings Cheap & ease of fabrication for application to off-
- the-shelf products: Laptops, PDAs etc.

### **COLLABORATION:**

•UTD:

•UTPA:

U of Florida:

JSC (EV):

Nanotube materials

EMI testing & test development Nanomaterials functionalization

Nanomaterials functionalization Testing, requirements



Translucent Appliqués: Potential coatings for LCD screens





EMI testing in collaboration with UTPA












## **Active Radiation Dosimeter**


### CHALLENGE:

- Acute radiation sickness poses a risk to astronaut health for interplanetary travel
  - Currently no "real-time" personal radiation detecting sensor for extravehicular activity
- Current technologies lack desired sensitivity



Particle Event Solar

#### Protection Earth's



### COLLABORATION:

High surface area nanomaterials can increase

SWCNTs to measure radiation dose rates and

total dose.


sensitivity

Use radiation sensitive functionalized

SOLUTION:

- JSC (SF)

- JSC (EB)JSC (EC)NASA Ames
  - Rice Univ.
- Dosimeter
- Advanced EVA Sensors
- Gas sensors
- PVAM
- Nanotube functionalization Radiation Testing



Radiation Testing




# Advanced Thermal Protection System (TPS) Repair

### CHALLENGE:

- Improve and expedite curing and repair processes for current missions
- Long duration missions need more effective repair processes: On Orbit/En Route/On the surface

### SOLUTION:

- Use microwave energy to heat nanotubes in polymer and ceramic matrices for localized heating, curing & bonding
  - Repair of RCC and tiles, CEV materials
- Potential commercial applications including composite curing



~ 1:1 Energy transfer in nanotubes

Microwaves: Heat



 Rice: Nanotube microwave research (Tour) Functionalized nanomaterials






# Thermal Radiation & Impact Protection (TRIPS)

### CHALLENGE:

- Thermal protection system with impact and radiation protection
- Lower weight = Greater performance
- Lower spacecraft complexity = Lower risk
- Lower risk = Greater safety



Carbon nanotubes for

char strength

Vacuum Impregnation

Gelling cycle

radiation protection Polyethylene for



Drying Cycle

 Enhanced radiation protection via integration Protection System (TPS) – additional strength

Impregnated Carbon Ablator (PICA) Thermal


Use SWCNT impregnated into Phenolic

SOLUTION:

Nextel and/or Kevlar fabric incorporated for

of polyethylene

impact protection



PICA with phenolic

Composites, Arc Jet Testing

TPS Lead

NASA Ames:

• JSC (ES3):

**COLLABORATION:** 



resin impregnated



PICA - Fiberform impregnation before



# Nanotechnology: Astronaut Health Management

### **Basic Biomedical Research**

- The role that forces play on cell mechanisms (gravitational forces)
- Molecular machines (ATPase, Kinesin, Microtubules, Polymerase, etc.)
- In vivo monitoring of ultra-low concentration proteins and biomolecules

## Personal Biomedical Monitoring

- Identification of molecular indicators for onset of conditions
- High sensitivity assays
- Short prep-time assays, no prep-time assays and in vivo monitoring
  - Multiple simultaneous assays

### Personal Countermeasures

- Timed drug release
- Targeted drug therapy
- Triggered drug release
- Indicators for drugs effectiveness

### Major Medical Operations

- Contrast agents to target specific sites for surgery
- Bio-mimetic or engineered compounds to help wound healing
- Miniaturized electron microscopes for biopsies

### Life Support

- High surface area materials for CO<sub>2</sub> removal
- Inorganic coatings that catalyze the revitalization of air and water
- Sensors to monitor harmful vapor/gases

### **Toxicology & Ethics**

- Biodistribution of nanoparticles
- Toxicology of nanoparticles
- Ethical use of information from nanotech devices

### Systems Integration

Develop 'common toolkit' for bio-nano chemistry and assembly processes

# ISC Nanomaterials Group

### MASA

# Collaborations

### Governmen

National Institute of Standards and Technology

Development of nanoscale measurement standards (Frieman)

Academia

 Production / purification (JSC) for use in SWNT composites (Siochi, Park, Smith) NASA Langley Research Center

 Nanotube characterization (Carr) Central Intelligence Agency

Oak Ridge National Lab.

CNT production, purification and characterization (Geohegan) Thermal characterization (Wang)

Advanced Nanotechnology Mat'ls and Applications (Smalley, Tour, Barrera)
 Computational Mat'ls Sci. (Yakobson)

Rice University

NASA-URETI: Texas A&M, Rice, UT Arlington, TSU, PrairieView A&M and UH

Nanotube characterization

 Mechanics / composites Radiation protection

· Nanoshells (Halas)

NASA Ames Research Center

Nanotubes (JSC) for sensors / modeling of HiPco (Meyyappan, Srivastava)

National Renewable Energy Lab CNT Purification (Heben, Dillon)

 Composites, characterization, purification (Maruyama, Strong) Air Force Research Lab.

Functionalization, purification, high temp. mat'ls (Meador, Gray)

NASA Gienn Research Center

Minister of the

Naval Research Lab.

Composites (Imam, Pehrsson) NASA Marshall Space Flight Center • Nanotubes, MMCs (Gill, Hudson)

National Institute for Occupational Safety and Health

Nanotube toxicology studies (Shvedova)

Los Alamos National Lab • Purification (O'Connell)

SouthWest NanoTechnologies, Inc. · SBIR - Nanotube production (Resasco)

Zyvex

SBIR – Dispersion (Randall)

· Production, purification, applications (Smith)

Carbon Nanotechnologies, Inc.

THE

UC Riverside Purification (Haddon)

Georgia Tech

Nanotube composite films (Ready)

GSRP, year 3 of 3 – Polymer chemistry, dispersion, composites (Mitchell, Krishnamoorti)

Michigan Tech
Summer Faculty Fellow - Composites (Caneba)

University of Houston

University of Pennsylvania

• CDDE - Thermal Mgmt. Matis (Fischer)

• Composites (Luzzi, Winey)

University of Paris 13 · Arc process (Farhat) University of Florida Isolated SWNTs (Rinzler)

University of Tennessee, Knoxville Nanoindentation (Penumadu)

Northwestern • Nanomechanics (Ruoff)

Thermal stability of nanotubes (Resasco)

University of Oklahoma

University of California - Davis Nanocrystalline Ceramics (Mukherjee)

LeTourneau University
Summer Faculty Fellow
Nanotube growth process (DeBoer)

Isotron • EMI shielding

NanoTechnologies of Texas, Inc. SBIR - Conductive fabrics (Chibante)

Penn State
Purification /
characterization
(Eklund)

Ionwerks
- Mass spectrometry (Schulz)

Inorganic Specialists

SBIR - Electrochemical capacitors (Firsich)

CFD of Laser process (Greendyke) University of Texas - Tyler

Wake Forest
Characterization of nanotubes (Carroll)

Materials and Electrochemical Research SBIR - Nanotube production (Louffy)

Eikos • EMI Shielding (Glatkowski)

Nanospectra
Thermal control coatings (Watkins)

RTF – Ceramic / nanotube composites (Riedell)

COI Ceramics

ReyTech SBIR - Ultracapacitors (Reynolds)

NanoRAM development (Siegel)

Nantero, Inc.

Resolution Performance Products - Epoxy / nanotube composites (Stark)

Hamilton-Sundstrand
CO<sub>2</sub> Scrubber (Papale)

Honda

Magnetic characterization (Harutyunyan)

GB Tech
• Fuel cells / CO<sub>2</sub>
scrubber (Huffman)

